

Differential for Truck



LUCKY PROGRESS CO.,LTD.

No.62, Furen St., West Dist., Taichung City 403 Taiwan

TEL: 886-4-23727596 FAX: 886-4-23727597

E-mail:lucky.tina@msa.hinet.net

FUSO

FUSO-D3 4D31/ 4D34 CANTER

FUSO-D4 FK61/6M61/6M60



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
6-34	6.16	MC863589	6-37	6.1	MC075131
6-40	6.66	MC863589S	6-40	6.6	MC075131S
7-37	5.28	MC061012	8-39	4.8	MC834997
8-39	4.87	MK499896	9-37	4.1	MC444937

FUSO-D5 FK612- FK622

FUSO-D8 6D16/ FM657/ FK



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
8-39	4.8	MC834741	6-40	6.6	MC839938
7-38	5.4	MC076705	6-37	6.1	MC817479
6-40	6.6	MC075140	7-39	5.5	MC814389
6-37	6.1	MC075141	7-36	5.1	MC150736
8-37	4.6	MC864104	8-37	4.6	MC150837
9-37	4.1	MC076530			

FUSO

**FUSO-D10R FV413/ FV415/ FV416/
FV419/ FV515/ FV514**

**FUSO-D10F FV413/ FV415/ FV416/
FV419/ FV515/ FV514**



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
6-45	7.5	MC809464	6-37	6.1	MC804122
6-43	7.1	MC411419	6-40	6.6	MC804124
6-41	6.8	MC411641	6-41	6.8	MC411641
6-40	6.6	MC804120/MC827163	6-43	7.1	MC411418
6-37	6.1	MC827160	6-45	7.5	MC809467
7-39	5.5	MC831408	7-36	5.1	MC831735
7-36	5.1		7-39	5.5	MC831408
8-37	4.6	MC320837	8-37	4.6	MC320837
11-38	3.4		5-37	7.4	
11-39	3.5				
11-42	3.8				

FUSO-D12R TRAILER/ DUMP TRUCK



GEAR NO	GEAR RATIO	PART NO.			
6-40	6.6	MC834813			
6-37	6.1				
7-39	5.5				
7-36	5.1	MC892921			
8-37	4.6	MC061889			
9-38	4.2				

HINO

14B-15B TOYOTA DYNA

HINO 300 41111-2030



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
8-45	5.62		6-35	5.8	41201-80187
7-39	5.57		7-45	6.4	41201-80209
			8-37	4.6	41201-80551
			6-41	6.8	41201-80511

HINO 500 41111-1991

HINO FF/ 3H/ FG/ 15 TONS JO8C/H07C 41111-1591



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
7-36	5.1	41201-E0120	7-45	6.4	41201-2910
9-39	4.3	41221-4551	7-43	6.1	41201-E0300
10-39	3.9	41221-4552	7-38	5.4	41201-2540
			8-41	5.1	41201-E0270

HINO

HINO FS 41111-1461

HINO 700/ 500R 41111-1811/ 41111-E0020



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
7-45	6.4	41201-13821	R 7-45	6.4	41201-3070
6-41	6.8	41201-1101	R 6-41	6.8	41201-3165

HINO 700/ 500R

HINO 700/500 KL



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
F 6-41	6.8	41201-3160	F 8-37	4.6	41201-3600-1
F 7-45	6.4	41201-3040			

UD

**FE6 CM86/ CM87/ CM88/ MK210/
MK211/ MK250/ MK251/ MK260**

FE6 RE8/ PF6/ FE6 (235P)



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
7-40	5.7	38110-Z5100	6-41	6.8	38110-90008-1
7-37	5.2	38110-Z5101	6-37	6.1	38110-90008-2/90569
			7-39	5.5	

CW520 F RF-RG-RH

CW520 R RF-RG-RH



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
F 6-41	6.8	38110-90475	R 6-41	6.8	38110-90502
F-6-39	6.5	38110-90477	R 6-39	6.5	38110-90503
F 5-37	7.4	38110-90475	R 5-37	7.4	38110-09501

ISUZU

KS NPR

FRR/ FSR



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
7-39	5.5		7-38	5.4	
7-43	6.1		8-41	5.1	
			10-39	3.9	

D6 FTR

D10R



GEAR NO	GEAR RATIO	PART NO.	GEAR NO	GEAR RATIO	PART NO.
6-39	6.5	1-41210-276	R 6-43	7.1	1-41210-294-0
7-39	5.5	1-41210-280-0	R 6-41	6.8	1-41210-909
7-43	6.1	1-41210-277-0	R 7-43	6.1	1-41210-4080
			R 7-45	6.4	1-41210-274
			R 7-39	5.5	1-41210-301-0

